

# TECHNICAL DATA SHEET

FT 536 / Index 00 - 01/03/2015





# **ORANET F** MULTI-PURPOSE DETERGENT MULTI-PURPOSE CLEANER AND DEGREASER FOR BIOLOGICAL PART WASHERS

### DEFINITION

Water-based degreaser for all mechanical metal parts to be degreased in heated part washers. Can be used with our ORAZYM 5327 micro-organisms.

### **ADVANTAGES**

- More effective thanks to special, powerful surfactants.
- Solvent-free. Free from VOCs, does not damage the ozone layer.
- Dissolves grease, oil, carbon residue, sludge, carbon deposit etc.
- Can be used hot in our dedicated 700091 and 700091XS part washers.
- Safe on plastics and varnishes.
- ORANET F is the ideal substitute for solvent-based degreasers.

#### **Operating method:**

536 ORANET F + ORAZYM 5327 at 38°C converts hydrocarbons into CO2 + H2O.

The bath is continually refreshed and does not become saturated. It last a long time and is more effective. Therefore, less waste is created.

## **APPLICATION FIELDS**

- ORANET F is particularly suitable for cleaning metals (iron, steel, stainless steel, aluminium, etc.) by hand or in a bath.
- Can be used for cleaning crude steel and aluminium.
- Clean unfinished or painted metal chassis (steel, stainless steel, copper).
- Clean rotors, stators, and circuit breakers.
- Cleaning the gearbox.
- The ideal alternative to solvent-based part washers.

#### 1/2 Head office

Parc Industriel de la Plaine de l'Ain - 225 allée des Cèdres - 01150 Saint-Vulbas - FRANCE Tel. +33 (0)4 74 40 20 20 - Fax +33 (0)4 74 40 20 21 www.orapi-maintenance.com

ORAPI © cannot know about every application for which the products are used nor their conditions of use. ORAPI © cannot be held responsible for the suitability of its products for a given use or specific purpose, for the methods of application over which it has no control. The information contained here can on no account be a substitute for the preliminary tests which are essential and which must be carried out in order to check the suitability of the product to each specific case. The user of the product described in this technical data sheet is solely responsible for all measures required to protect people and property from hazards that may arise from the implementation and/or use of this product. Therefore, ORAPI © renounces any implicit or explicit guarantees, including guarantees relating to marketability of a certain purpose, resulting from the sale or use of its products. In particular, ORAPI © renounces any claims for incidental or consequential damages whatsoever, including financial operating losses.



# **TECHNICAL CHARACTERISTICS**

Aspect	transparent liquid
Colour	
рН	< 9.8
Density at 20°C	1.032
Flash point	non-inflammable
VOCs	0 %

# **INSTRUCTIONS FOR USE**

• Can be used neat and hot in our dedicated 700091 and 700091XS part washers.

- Add **ORAZYM 5327** micro-organisms as soon as it starts up to ensure the optimum bioremedication of the oils and greases.

- Add one tablet as soon as it is switched on then, depending on your use, add one table every 4 to 6 weeks.

## PACKAGING

20 litre jerry can

Ref. 2536O1

x 1

# INFO

Collection of used solvents: please contact us. ORAPI handles everything. Collection, transport, destruction, treatment certificate.

#### 2/2 Head office

Parc Industriel de la Plaine de l'Ain - 225 allée des Cèdres - 01150 Saint-Vulbas - FRANCE Tel. +33 (0)4 74 40 20 20 - Fax +33 (0)4 74 40 20 21 www.orapi-maintenance.com

ORAPI © cannot know about every application for which the products are used nor their conditions of use. ORAPI © cannot be held responsible for the suitability of its products for a given use or specific purpose, for the methods of application over which it has no control. The information contained here can on no account be a substitute for the preliminary tests which are essential and which must be carried out in order to check the suitability of the product to each specific case. The user of the product described in this technical data sheet is solely responsible for all measures required to protect people and property from hazards that may arise from the implementation and/or use of this product. Therefore, ORAPI © renounces any implicit or explicit guarantees, including guarantees relating to marketability or suitability of ra certain purpose, resulting from the sale or use of its products. In particular, ORAPI © renounces any cincidental or consequential damages whatsoever, including financial operating losses.